

## FOOD FLASK USE AND CARE INSTRUCTIONS



### TO USE:

1. Separate all parts and hand wash in soapy water, rinsing thoroughly before use. Dry completely before reassembling.
2. For best results, preheat by filling with boiling water or pre-cool by filling with cold water or ice. Empty after 5 minutes and fill the base with desired contents.
3. Fill at arm's length to prevent accidental scalding - do not fill past measurement lines and leave at least 10mm between contents and underside of the lid.
4. Replace the lid tightly to retain temperature.
5. Always keep upright when travelling.
6. To open, hold onto flask base, keep away from face and unscrew lid.
7. Clean thoroughly after each use.



### CAUTION:

- If filling with boiling liquid, allow to cool with lid open for at least 3 minutes before closing.
- Keep out of reach of children & be cautious while using this product with hot contents.
- Check temperature of contents prior to consuming.
- Do not overfill or shake when full.
- Do not drink directly from the flask.
- To minimise bacterial growth, do not keep dairy or other contents that can spoil easily in this container for prolonged periods.

### CARE:

- Hand wash only.
- Do not immerse in water.
- Dry all parts thoroughly after washing and store with lid off.
- Do not use for carbonated drinks or dry ice.
- Do not use in oven, freezer or microwave.
- Do not use abrasive cleaners containing bleach chlorine or other abrasives and harsh chemicals on any part of the flask.

	Duration Cold	Duration Cold
Wonderwall Flask 500mL	9	7
Stainless Steel Food Flask 400mL	9	7
Stainless Steel DW Food Flask 350mL	12	6
Wide Mouth Food Jar 500mL	12	6
Stainless Steel Food Flask 500mL	12	9
Active Food Flask 650mL	9	7